

Universal Electronic Fan Timer

Replaces all others. The new universal platform that will not only integrate control of all combustion blower and circulating operations in a gas warm air appliance but also replace most ST9120, ST9141 and ST9160 fan timer boards. Save room on your truck or on your shelves with a supply of ST9120U1011 timers and know you're covered.

When selecting fan timers for your next job, look for these Honeywell features:

- Universal application
- Easy installation
- Quality construction for long service life



ST9120U1011

- Replaces 44 existing Honeywell controls to reduce inventory
- Integrates control of all combustion blower and circulating fan operations in a gas warm-air appliance
- Replaceable fuse
- DIP switch selectable heat and cool delay on and off times
- Diagnostic LED
- EAC and HUM convenience terminal connections and continuous low speed indoor air circulation are provided

ST9120U REPLACES OVER 44 EXISTING MODELS			
ST9101A1006	ST9120C3019	ST9120C4038	ST9100B1001
ST9101A1014	ST9120C4008	ST9120U1003	ST9100B1019
ST9101A1022	ST9120C4010	ST9141A1002	ST9100B1027
ST9120A2004	ST9120C4040	ST9141A1028	ST9100B1035
ST9120B1005	ST9120C4057	ST9141B1001	ST9100B1043
ST9120C1012	ST9120C5005	ST9150A1003	ST9100B1050
ST9120C1020	ST9120C5013	ST9150B2000	ST9100B1068
ST9120C2002	ST9120C6009	ST9150B2019	ST9100B1076
ST9120C2010	ST9120C6024	ST9150B2026	ST9100B1084
ST9120C2028	ST9120C2032	ST9150B2034	ST9100C1000
ST9120C3000	ST9120C4004	ST9100A1002	ST9100C1018

Universal Electronic Fan Timer OEM Replacement Guide

Replaced Control Model Number	Original OEM Appliance	RECOMMENDED DIP SWITCH SETTING				
		1	2	3	4	5
ST9101A1006	Ricam	off	off	off	off	off
ST9101A1014	Ricam	off	off	off	off	off
ST9101A1022	Teco	off	off	off	off	off
ST9120A1006	Amstrong	off	off	off	off	off
ST9120A2004	Amstrong	on	off	on	off	off
ST9120B1005	Ducane	off	on	off	off	off
ST9120C1012	Synchronal	on	off	off	off	off
ST9120C1020	Nucor	on	off	off	off	off
ST9120C2002	Nuk	off	off	off	off	off
ST9120C2010	Ducane	off	off	off	off	off
ST9120C2028	Amstrong	off	off	off	off	on
ST9120C3000	ICP	off	off	on	on	off
ST9120C3018	Barco	on	off	off	off	on
ST9120C4008	ICP	off	off	on	on	off
ST9120C4016	ICP	off	off	on	on	off
ST9120C4040	ICP	off	off	on	on	off
ST9120C4057	ICP	off	off	on	on	off
ST9120C5005	ICP	off	off	on	off	off
ST9120C5013	ICP	off	off	on	off	off
ST9120C6009	Gasifier	off	off	on	off	on
ST9120C6024	ICP	on	off	off	on	off
ST9120C6028	ICP	off	off	off	on	off
ST9120C6032	Skensark	off	on	off	on	off
ST9120C6038	Skensark	off	on	off	off	on
ST9120C6044	ICP	off	off	on	on	off
ST9120C6050	ICP	off	off	on	on	off
ST9120C6057	ICP	off	off	on	on	off
ST9120C6068	ICP	off	off	on	off	off
ST9120C6076	ICP	off	off	on	off	off
ST9120C6084	ICP	off	off	on	off	off
ST9120C6092	ICP	off	off	on	on	off
ST9120C6100	ICP	off	off	on	on	off
ST9120C6108	ICP	off	off	on	on	off
ST9120C6116	ICP	off	off	on	on	off
ST9120C6124	ICP	off	off	on	on	off
ST9120C6132	ICP	off	off	on	on	off
ST9120C6140	ICP	off	off	on	on	off
ST9120C6148	Teco	off	off	on	on	off
ST9120U1003	Teco	off	off	on	off	off
ST9141A1002	Corradicabo Industries	off	off	on	off	on
ST9100B1005		off	off	off	off	off
ST9100B1068	Amstrong	on	off	off	off	on
ST9100B1076	Ducane	off	off	off	off	off
ST9100B1084	ICP	off	off	on	off	on
ST9100C1000		off	off	off	off	off
ST9100C1018	ST9120U Factory Default Setting	off	off	off	off	off

For a complete cross-reference, visit www.customer.honeywell.com